

Installation Instructions Atto® / Atto® Dark

2521 & 2535 Atto® 2570 Atto® Dark

Atto®

Atto® Dark



Dear customer,
Thank you for choosing Kuryakyn. Please read and understand these instructions before deciding whether you would like to do the installation yourself or have it done by a professional.

All Kuryakyn by Kellermann lighting products are ECE-approved for motorcycles as documented by the approval mark engraved into the housing or lens. This means that you may use the products instead of the original indicator lights without any entry in your vehicle documents or presentation to a vehicle inspection organization. **You do not need to carry any documentation with you. This applies to all motorbikes licensed under EU law and the corresponding lights. Certificates are available at www.Kuryakyn.com.**

ATTENTION! Kuryakyn by Kellermann lighting is not DOT or FMVSS #108 compliant.

ATTENTION! The warranty will not apply if the turn signal has not been correctly installed or connected to the electrical supply on your motorcycle. Do not carry out the installation unless you are qualified to do so; otherwise, leave the installation and connection work for your indicator to a qualified repair shop. The warranty does not apply to damage due to wrong connection or excess voltage (such as due to a defective alternator regulator).

ATTENTION! Improper mechanical installation or orientation of turn signals may invalidate your motorcycle's roadworthiness and insurance protection, or even lead to accidents. Before every usage of your vehicle, check whether the indicators are correctly mounted and fully functional.

ATTENTION! Your turn signals may heat up during use. Contact with bare skin or heat-sensitive objects may lead to damage or injury.

ATTENTION! Voltage – 19v Max. Over voltage voids warranty
Motorcycles with voltage peaks can damage Kuryakyn by Kellermann products. The problem can be solved easily by installing suppressor diodes. Verify before installation that your vehicle's electrical system operated in a normal 12-15 v range with no peaks that exceed 19 v.

Warranty is void if operating with over-voltage.

CLEANING ADVICE! Your new Kuryakyn by Kellermann products are premium-quality products. In order to enjoy them long time and maintain the warranty we recommend not to use any cleansers with alkaline/acid and/or grinding substances or steel wool. We also advise not to use steam cleaners.

INSTALLATION

ATTENTION! Make sure that your motorcycle is standing firmly before you start work, as a fall may lead to damage to the motorcycle or injury to you or others.

Remove existing indicators. Mount the Bullet Atto turn signals by fabricating a bracket or by drilling a 5 mm diameter hole. Fasten the turn signal at 44 in-lbs (5 Nm) with the provided nut. Use adapters (sold separately) if necessary. Make sure that the area where the wires emerge is protected from splash water. Mount the turn signal in such a way that the beams run horizontally in your bike's direction of travel. Proper alignment is important for your safety in traffic, as a bike with incorrectly aligned lights is easy to overlook on the road.

If living in a country that requires ECE compliance, refer to the following measurements for selecting your mounting location:

Position - In width:

For front indicators: minimum distance of 240 mm
For rear indicators: minimum distance of 180 mm

Minimum distance between the illuminating surface of the indicators and the headlamp:

75 mm

In height:

350 mm -1200 mm above the ground

In length:

The distance between the rear indicators and the rearmost limit of vehicle's over-all length shall not exceed 300 mm

Geometric visibility:

Horizontal angles: 20° inwards, 80° outwards
Vertical angles: 15° above and below the horizontal

ELECTRICAL CONNECTION

Cut the wires of the original indicators between the indicator and the connector, allowing enough slack in the wire for the connection of the new indicator. By doing this the wiring loom stays untouched.

Connect the grey cable to positive (+) terminal and the black cable to negative (-) terminal.

To connect the wires of the indicator to the wires of the original connector use the provided crimp connectors and shrink tubings. First push one of the shrink-on tubes over one of the wires you want to connect and remove 1/4" of insulation on the end of each cable. Then push both bare ends of the wire into a crimp connector and crimp it with an appropriate tool. Then pull the shrink-on tube over the connection and heat it up equally until it fits tight over the complete length of the connector.

Test the function of the turn signals.

Route the cables in a way that they are protected from splash water and fasten them using zip ties.

This completes the installation.

Refer to www.kuryakyn.com for additional information and a range of accessories. If you have any suggestions or questions, please do not hesitate to contact us by email (info@kuryakyn.com) or phone 866-277-9598.

INDICATOR FLASH RATE

The flashing frequency can change when converting the original indicators. The installation of a load-independent flasher relay (e.g. R2) or a multifunctional assistance system (e.g. CR4®) will solve the problem. If the installation is not possible or not favored, then parallel connected power resistors (i.LOAD) will be an option.

We are happy to answer any questions you may have with regards to converting your indicators, we are certain we can help you.

If you are not sure which electronic equipment you require, please contact us via <http://www.kuryakyn.com>, info@kuryakyn.com, or call us: **866-277-9598**.

ATTENTION! Before each use of the vehicle, check the functionality of the indicator lights.

The Kuryakyn by Kellermann Atto®/Atto® dark is equipped with the tried-and-trusted **Longlife Protection Guard®** circuit, which ensures extremely long life with LED technology.