



STILETTO PEGS with STIRRUPS

4477

PARTS INCLUDED

- 1 Left Stiletto Peg with Stirrup and Male Mount
- 1 Right Stiletto Peg with Stirrup and Male Mount
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Hex Wrenches, Long Hex Wrench Sockets and Ratchet, Set of Combination Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

NOTE: Optional domed end caps are available to replace the pointed end caps. (Sold separately) .

STEP 2 Remove the stock peg from the peg mount. Pay attention to any spacers or washers installed between the peg mount and the clevis, it may be helpful later. Keep the mounting hardware, it will be reused.

STEP 3 Install the new Stiletto Peg and Stirrup using any spacers or washers removed in Step 2. Line up the new peg mount hole with the hole in the clevis.

STEP 4 Secure the peg in the clevis using the stock hardware removed in Step 2. Check that the peg mount is installed correctly and the peg is able to fold upward.

STEP 5 Repeat STEP 2 through STEP 4 for the other side.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.

• Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



ADJUSTING THE POSITION OF THE FOOTPEG:

WARNING! EVEN IF THE STILETTO PEGS AND STIRRUPS APPEAR TO BE POSITIONED CORRECTLY, YOU MUST COMPLETE THE FOLLOWING STEPS. IT IS IMPERATIVE THE 5/16"-18 X 2" SOCKET HEAD CAP SCREWS (FIG.1-R) AND 7/8"-20 HEX NUT (FIG 1-K) ARE TIGHTENED SECURELY SO THE PEGS CANNOT ROTATE OR FALL OFF DURING WHILE IN USE. FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH.

- STEP 6** With a hex wrench, remove the #5-40 x 3/8" socket head cap screws, FIG.1-U, pointed end cap, FIG.1-T, and knurled trim ring, FIG.1-S, from one of the Stiletto Pegs. Remove the end rubber, FIG.1-P, from the peg body, FIG.1-M, to expose the 5/16"-18 x 2" socket head cap screw, FIG.1-R.
- STEP 7** With a long hex socket, remove the 5/16"-18 x 2" socket head cap screw and slide the peg off the mount.
- STEP 8** Using an open end wrench or 12" adjustable wrench, loosen the 7/8"-20 nut, FIG.1-K. Use your judgment and set the angle of the stirrup to what would appear to be the natural angle needed to support your foot and securely tighten the 7/8"-20 nut. Slide the peg back in place, install the 5/16"-18 x 2" socket head cap screw finger tight, then sit on the bike to confirm the stirrup position. Repeat the process until the stirrup is located in the optimum position.
- STEP 9** Adjust the angle of the peg so the rider's or passenger's foot sits squarely on the rubber pads when seated on the motorcycle. Securely tighten the 5/16"-18 x 2" socket head cap screw once the adjustment is complete.
- STEP 10** Reinstall end rubber, knurled trim ring, end cap, and the #5-40 x 3/8" socket head cap screws.
- STEP 11** Repeat STEP 6 through STEP 10 for the other Stiletto Peg with Stirrup.

WARNING! THE INSTALLATION OF AFTERMARKET PEGS MAY AFFECT GROUND CLEARANCE WHEN CORNERING.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

