



## CRUISE PEG MOUNTS 4540

**FITS: '03-UP VTX1800 RETRO, VTX1800S, VTX1800N**

PART #	INCLUDED
604540R	1 Right Peg Mount Assembly Including the Following:
404540R	1 Right Highway Peg Mount
608061	1 Clevis Mount With 1/2"-13 Right Hand Threads Assembly Including:
408061	1 Clevis
200236	1 3/8"-16 x 1" SHCS
200413	1 "D" Spring Washer
200060	1 1/2"-13 x 1" HHCS 18-8
200077	1 1/2" INT L/W Chrome
604540L	1 Left Peg Mount Assembly Including the Following:
404540L	1 Left Highway Peg Mount
608061	1 Clevis Mount with 1/2"-13 Right Hand Threads Assembly Including:
408061	1 Clevis
200236	1 3/8"-16 x 1" SHCS
200413	1 "D" Spring Washer
200060	1 1/2"-13 x 1" HHCS 18-8
200077	1 1/2" INT L/W Chrome
904550	1 Hardware Kit Including the Following:
200296	6 5/16"-18 Nylon Insert L/N Zinc
200533	6 5/16"-18 X 3/4" BSCS 18-8 SST
200355	6 5/16" SAE F/W Zinc (Steel)
304540	1 Installation Instructions

### THANK YOU FOR CHOOSING KÜRYAKYN!

### PROCEDURE

**STEP 1** Remove the rubber pad on your floor board. This can be done by pulling up on the back side of the rubber (closest to engine) and pull upward.

**STEP 2** Remove the metal floorboard by removing the clip and washer of the mounting swivel pin, and then pull the pin out. Be very careful to pay attention to the placement of the spring, you will need to reinstall it the same way it comes out. The curved end of the spring goes into the board. See PIC.1.

-cont.-



### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn™ product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA™ All Rights reserved.



**STEP 3** Place the corresponding peg mount on the bottom of the board to get it in the correct position. You are using this mount as a template to mark the three holes to be drilled. See [PIC.2](#) and [PIC.3](#) for the correct position. These photos are the right floor board.

**Kuryakyn™**

**STEP 4** Mark the points where the holes need to be drilled. Use a center punch and a hammer to mark the center of the hole to be drilled. You will not need to hit this very hard, it will mark easily. This needs to be done so the drill bit does not walk. Drill the holes using an 11/32 bit.

**STEP 5** Mount the arm to the board using the supplied fasteners, washers, and nuts. Tighten the fasteners.

**STEP 6** Remount the board in the reverse order that it was removed in STEP 2.

**STEP 7** Apply a small amount of lubricant to the 4 rubber nipples on the bottom of the rubber pad. WD 40 works great for this. Install the rubber pad to the board pulling the nipples thru the mount holes.

**STEP 8** Repeat the above steps for the opposite side.

**STEP 9** You can now install the pegs you have purchased separately. Simply remove the screw in the clevis. See [PIC.4](#). Insert the male mount peg in the clevis with the "D" washer and insert and tighten the screw.

**PIC.2**



**PIC.3**



**PIC.4**



*Ride On!*

**PAGE**

**2**

**CRUISE PEG MOUNTS**

**INSTALLATION**